

# KENWOOD

## STAGE 3

**KDC-8007**  
**KDC-7007**

CD-RECEIVER

## **INSTRUCTION MANUAL**

AMPLI-TUNER-LECTEUR DE CD

## **MODE D'EMPLOI**

REPRODUCTOR DE DISCOS COMPACTOS RECEPTOR DE FM/AM

## **MANUAL DE INSTRUCCIONES**

KENWOOD CORPORATION

**Take the time to read through this instruction manual.**

**Familiarity with installation and operation procedures will help you obtain the best performance from your new CD-receiver.**

### **For your records**

Record the serial number, found on the back of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your KENWOOD dealer for information or service on the product.

Model KDC-8007/7007 Serial number \_\_\_\_\_

©B64-0979-00 (KW)

**COMPACT**  
**disc**  
**DIGITAL AUDIO**

# Contents

## Before use

|                              |   |
|------------------------------|---|
| Warning .....                | 3 |
| Safety precautions .....     | 5 |
| Handling Compact discs ..... | 7 |
| Buttons and Display .....    | 8 |

## Basic operations

|                                    |    |
|------------------------------------|----|
| Stealth Retraction Mechanism ..... | 11 |
| Volume .....                       | 12 |
| Attenuator .....                   | 12 |
| Loudness .....                     | 12 |

|   |    |
|---|----|
| <b>Basic operations of remote</b> ..... | 12 |
|---|----|

## Tuner features

|   |    |
|---|----|
| Tuning .....                                | 14 |
| Station Preset Memory .....                 | 15 |
| Auto Memory Entry .....                     | 15 |
| Clean Reception System Circuit (CRSC) ..... | 15 |
| Direct Access Tuning .....                  | 15 |
| Station Name Preset (SNPS) .....            | 16 |
| Station Name Preset Play (SNPP) .....       | 17 |

## CD player features

|   |    |
|---|----|
| Playing CDs .....                             | 17 |
| Switching Display for CDs .....               | 18 |
| Fast Forwarding and Reversing Disc Play ..... | 18 |
| Track Search .....                            | 18 |
| Direct Track Search .....                     | 18 |
| Track Repeat .....                            | 18 |
| Track Scan .....                              | 19 |
| Random Play .....                             | 19 |

## Disc changer control features

|   |    |
|---|----|
| Playing Discs Using a Disc Changer .....      | 19 |
| Switching Display for Discs .....             | 20 |
| Fast Forwarding and Reversing Disc Play ..... | 20 |
| Track Search .....                            | 20 |
| Disc search .....                             | 21 |
| Track /Disc Repeat .....                      | 21 |
| Random Play .....                             | 21 |
| Magazine Random Play .....                    | 22 |
| Track Scan .....                              | 22 |
| Disc Scan .....                               | 22 |
| Presetting Disc Names .....                   | 23 |
| Direct Track Search .....                     | 24 |
| Direct Disc Search .....                      | 24 |
| Disc Name Preset Play .....                   | 24 |

## Other features

|                                      |    |
|--------------------------------------|----|
| Audio Control Setting .....          | 25 |
| Table of Audio Control Setting ..... | 25 |
| Clock Display .....                  | 26 |
| Adjusting Time .....                 | 26 |
| Selectable Illumination .....        | 26 |
| Valet Mode .....                     | 26 |
| Non-fading Preout .....              | 26 |
| Security Code .....                  | 27 |

## Installation

|  |    |
|--|----|
| Accessories .....                      | 28 |
| Installation Procedure .....           | 28 |
| Connecting Wires to Terminals .....    | 29 |
| Installation (non-Japanese cars) ..... | 30 |
| Installation (Japanese Cars) .....     | 30 |
| Removing the Unit .....                | 32 |

|                                    |    |
|------------------------------------|----|
| <b>Troubleshooting Guide</b> ..... | 33 |
|------------------------------------|----|

|                             |    |
|-----------------------------|----|
| <b>Specifications</b> ..... | 36 |
|-----------------------------|----|



## Dear Customer:

Selecting fine audio equipment such as the unit you've just purchased is only the start of your musical enjoyment. Now it's time to consider how you can maximize the fun and excitement your equipment offers. This manufacturer and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion — and, most importantly, without affecting your sensitive hearing.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level **BEFORE** your hearing adapts.

### To establish a safe level:

- Start your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, and without distortion.

### Once you have established a comfortable sound level:

- Set the dial and leave it there.

Taking a minute to do this now will help to prevent hearing damage or loss in the future. After all, we want you listening for a lifetime.



## We Want You Listening For A Lifetime

Used wisely, your new sound equipment will provide a lifetime of fun and enjoyment. Since hearing damage from loud noise is often undetectable until it is too late, this manufacturer and the Electronic Industries Association's Consumer Electronics Group recommend you avoid prolonged exposure to excessive noise. This list of sound levels is included for your protection.

### Decible Level

### Example

|    |   |
|----|---|
| 30 | Quiet library, soft whispers                                      |
| 40 | Living room, refrigerator, bedroom away from traffic              |
| 50 | Light traffic, normal conversation, quiet office                  |
| 60 | Air conditioner at 20 feet, sewing machine                        |
| 70 | Vacuum cleaner, hair dryer, noisy restaurant                      |
| 80 | Average city traffic, garbage disposals, alarm clock at two feet. |

### THE FOLLOWING NOISES CAN BE DANGEROUS UNDER CONSTANT EXPOSURE

|     |   |
|-----|---|
| 90  | Subway, motorcycle, truck traffic, lawn mower       |
| 100 | Garbage truck, chain saw, pneumatic drill           |
| 120 | Rock band concert in front of speakers, thunderclap |
| 140 | Gunshot blast, jet plane                            |
| 180 | Rocket launching pad                                |

Information courtesy of the Deafness Research Foundation.



## **▲Warning**

### **▲CAUTION**

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

In compliance with Federal Regulations, following are reproductions of labels on, or inside the product relating to laser product safety.

KENWOOD CORPORATION  
2967-3, ISHIKAWA-CHO,  
HACHIOJI-SHI  
TOKYO, JAPAN

KENWOOD CORP. CERTIFIES THIS EQUIPMENT  
CONFORMS TO DHHS REGULATIONS NO.21 CFR  
1040. 10, CHAPTER I, SUBCHAPTER J.

Location : Bottom Panel

### **FCC WARNING**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

### **NOTE**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment may cause harmful interference to radio communications, if it is not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **NOTE**

This Class B digital apparatus meets all requirements of the Canadian interference-Causing Equipment Regulations.

### **▲WARNING**

**To prevent injury or fire, take the following precautions:**

- Insert the unit all the way in until it is fully locked in place. Otherwise it may fall out of place when jolted.
- When extending the ignition, battery, or ground wires, make sure to use automotive-grade wires or other wires with a 0.75mm<sup>2</sup> (AWG18) or more to prevent wire deterioration and damage to the wire coating.
- To prevent a short circuit, never put or leave any metallic objects (such as coins or metal tools) inside the unit.
- If the unit starts to emit smoke or strange smells, turn off the power immediately and consult your Kenwood dealer.
- Make sure not to get your fingers caught between the faceplate and the unit.
- Be careful not to drop the unit or subject it to strong shock.  
The unit may break or crack because it contains glass parts.
- Do not touch the liquid crystal fluid if the LCD is damaged or broken due to shock. The liquid crystal fluid may be dangerous to your health or even fatal.  
If the liquid crystal fluid from the LCD contacts your body or clothing, wash it off with soap immediately.

### **▲CAUTION**

**To prevent damage to the machine, take the following precautions:**

- Make sure to ground the unit to a negative 12V DC power supply.
- Do not open the top or bottom covers of the unit.
- Do not install the unit in a spot exposed to direct sunlight or excessive heat or humidity. Also avoid places with too much dust or the possibility of water splashing.
- Do not subject the faceplate to excessive shock, as it is a piece of precision equipment.
- When replacing a fuse, only use a new one with the prescribed rating. Using a fuse with the wrong rating may cause your unit to malfunction.
- To prevent a short circuit when replacing a fuse, first disconnect the wiring harness.
- Do not place any object between the faceplate and the unit.
- Do not use your own screws. Use only the screws provided. If you use the wrong screws, you could damage the unit.

### **IMPORTANT INFORMATION**

You cannot connect the unit directly to the following CD automatic changers. If you want to use older changers with the unit, follow the directions below according to the type of changer you own:

#### **• KDC-C200 / KDC-C300 / KDC-C400**

Use the extension cable and the control box attached to the CD changer, and the optional CA-DS100 converter cord.

#### **• KDC-C301 / KDC-C600 / KDC-C800 / KDC-C601 / KDC-C401**

Use the extension cable attached to the CD changer, and the optional CA-DS100 converter cord.

#### **• C705i / C705si**

Use the extension cable attached to the CD changer, and the optional CA-K300 converter cord.

#### **• KDC-C100 / KDC-C302 / C205 / C705 / non-Kenwood CD changers**


Cannot be used with this model.

### **▲CAUTION**

**You can damage both your unit and the CD changer if you connect them incorrectly.**

### NOTE

- If you experience problems during installation, consult your Kenwood dealer.
- If the unit fails to operate properly, press the RESET button. When the faceplate is not visible, press "the touch-sensitive spot" at the rear of the faceplate (as illustrated on p.11) to make the faceplate control appear. The unit returns to factory settings when the RESET button is pressed. If the unit still fails to operate properly after the RESET button has been pressed, contact your local KENWOOD dealer for assistance.



RESET button

- We recommend the use of the Security Code function (see p.27) to prevent theft.

### Cleaning the Unit

If the front panel gets dirty, turn off the power and wipe the panel with a dry silicon cloth or soft cloth.

### CAUTION

Do not wipe the panel with a hard cloth or a cloth dampened by volatile solvents such as paint thinner and alcohol. They can scratch the surface of the panel and/or cause the indicator letters to peel off.

### Lens Fogging


Right after you turn on the car heater in cold weather, dew or condensation may form on the lens in the CD player of the unit. Called lens fogging, CDs may be impossible to play. In such a situation, remove the disc and wait for the condensation to evaporate. If the unit still does not operate normally after a while, consult your Kenwood dealer.

## Handling Compact discs


**Playing a CD that is dirty, scratched or warped can cause the sound to skip and the unit to operate incorrectly, resulting in worsened sound quality. Take the following precautions to prevent your CDs from getting scratched or damaged.**

### Handling CDs

- Do not touch the recorded side of the CD (the side opposite the label) when holding it.



- Do not stick tape on either side of the CD.




### Storing CDs

- Do not store CDs in areas exposed to direct sunlight (such as a car seat or the dashboard) or other hot places.
- Remove CDs from the unit when not listening to them for a while, and put them back in their cases. Do not pile up CDs that are removed from their cases or prop them against something.


### Cleaning CDs

If a CD has gotten dirty, wipe it off gently using a commercially available cleaning cloth or a soft cotton cloth, starting from the center of the disc and moving outward. Do not clean CDs with conventional record cleaners, anti-static formulas, or chemicals such as paint thinner or benzene.



### Checking New CDs for Burrs

When playing a new CD for the first time, check that there are not any burrs stuck to the perimeter of the disc or in the central hole. CDs with burrs stuck on them may not load properly or may skip while playing. Remove burrs using a ballpoint pen or a similar utensil.




### Do Not Load CD Accessories

Do not use commercially available CD accessories that can be loaded into the CD slot, such as stabilizers, protective sheets, or CD cleaning discs, since they can cause the unit to malfunction.

### Removing the CD

Only remove the CD from the machine in a horizontal direction, holding it flat. You may damage the surface of the CD if you try pulling it down as it ejects.





### CAUTION

#### Do Not Load 3-in. CDs in the CD slot



If you try to load a 3 in. CD with its adapter into the unit, the adapter might separate from the CD and damage the unit.

# Buttons and Display

## Basic operations





## Tuner features







## CD player features




## Disc changer control features




# Buttons and Display

## Other features




Clock display



## Remote

Optiona



## Stealth Retraction Mechanism

**You can help prevent theft of the unit by reversing the faceplate so that the control panel cannot be seen, hiding the unit, and shutting off the audio.**

### Power ON/OFF:

When you turn your vehicle's ignition on, the unit's power will also turn on, with the faceplate reversing to show the control panel.

When you turn your vehicle's ignition off, the faceplate will reverse to hide the control panel, and the unit's power will turn off.

#### NOTE

- The first time you use the unit, you need to press "the touch-sensitive spot" at the rear of the faceplate. (as illustrated)
- When the moving faceplate is hit by an object, it will stop and return to its original state. Remove the object and repeat the action.

#### CAUTION Using the Unit in Vehicles with Covered Consoles

- Make sure the console is uncovered while the faceplate is reversed.
- Do not exert any excess force on the movable parts of the unit, including the faceplate, as it can cause failure in the unit's mechanism.

### Hiding the unit with the ignition turned on (forced closing):

Keep pressing the CLOSE/PWR OFF button for at least one second.

The faceplate will reverse, hiding the unit. The unit will turn off.

#### NOTE

- When the closing faceplate is hit by an object, the unit will turn off without the faceplate closing all the way. Remove the object and press the TUN button to turn the unit back on, then turn it off again to have it close properly.
- While the control panel is moving, pressing the buttons will not have any effect. Do not try to press the buttons on the control panel as the faceplate is moving, as excessive force may damage the unit.
- During the forced closing of the unit (i.e., having the unit left


closed while ignition is turned on), the faceplate will not open no matter how often the ignition is turned on or off, unless "the touch-sensitive spot" at the rear of the faceplate is pressed in order to open it. You can prevent tampering of the unit when letting someone else drive your car by keeping it closed this way.

### To cancel the stealth retraction mechanism's forced closing of unit and open control panel:

Press "the touch-sensitive spot" at the rear of the faceplate. (as illustrated)

### Selecting the standby mode:

Press the TUN button repeatedly and switch to "ALL OFF." When "ALL OFF" is displayed, the standby mode is activated. The standby mode turns all functions off while leaving the power to the unit on. Use this mode when you want to have the display illuminated but don't want to listen to anything.



Touch-sensitive spot

#### NOTE Touch sensitive spot

The invisible switch is hiding behind the touch-sensitive spot. Press the hollow spot (invisible switch) to open.

## Basic operations (See page 8)

### Volume

#### Increasing Volume:

Press the  $\wedge$  button to turn up the volume.

#### Decreasing Volume:

Press the  $\vee$  button to turn down the volume.

### Attenuator

This function allows you to turn down the volume quickly.

#### Turning Attenuator On/Off:

Press the ATT button to switch the attenuator on and off.

When the attenuator is on, the ATT indicator blinks.

When the attenuator is off, the volume returns to the original level.

#### NOTE

Turning the volume all the way down deactivates the attenuator function.

### Loudness

This function amplifies low and high tones when the volume is turned down.

The LOUD indicator lights up when the loudness function is on.

#### Turning Loudness On/Off:

Press the LOUD button for at least one second to switch the loudness on and off.

#### NOTE

The loudness function does not affect non-fading pre-out.

## Basic operations of remote (See page 10) Optional

### CAUTION

Do not set the remote on hot places such as above the dashboard.

### Replacing the Lithium Battery:


Use one lithium battery (CR2025).

Remove the case following the instructions as illustrated.

To open

① Keep on slide

② Pull out.



Insert the battery with the  $+$  and  $-$  poles aligned properly, following the illustration inside the case.

### WARNING

Store unused lithium batteries out of the reach of children. Contact a doctor immediately if the battery is accidentally swallowed.

## All Modes

- **VOL. buttons**  
Press the  $\wedge$  button to turn the volume up.  
Press the  $\vee$  button to turn the volume down.
- **TUNER button**  
Selects the tuner mode. Pressing this button again selects the standby mode.
- **CD button**  
Selects the CD mode.
- **CD•MD CH button**  
Selects the disc changer mode. When two disc changers are connected to the unit, the disc changer mode will be split into disc changer mode 1 and disc changer mode 2, and each press of this button switches between them.

### NOTE

The KCA-S200, which is sold separately, must be used when two disc changer units are connected.  
When the KDC-C810 is the directly connected disc changer (disc changer 1), two units may be controlled even without the KCA-S200.

## Tuner Mode

- **Number/ letter entry buttons**  
Press buttons #1-6 to recall preset stations.  
During direct access tuning, use these buttons to input the frequency of the station.  
Use to enter letters (alphabetical) during station name preset.
- **TUNE buttons**  
Press the TUNE— button to make decreasing seeks (using the preset tuning mode).  
Press the TUNE+ button to make increasing seeks (using the preset tuning mode).  
Use to move the cursor left or right during station name input.
- **AM/FM button**  
Press the AM button to select the AM band.  
Press the FM button to select and switch between FM1, FM2, and FM3 bands.  
During station name input, selects digits and symbols.
- **DIRECT/OK button**  
Selects the direct access tuning mode, used to input frequencies directly. Press this button again to cancel the mode while it is operating.  
During station name input, stores the already input data in memory and ends the input mode.  
During Station name preset play mode, selects station.
- **DNPP button**  
Enters and cancels the Station Name Preset Play mode.

## CD Mode

- **Number buttons**  
Used to specify the track number used in direct track searches.
- **TRACK buttons**  
Press the TRACK- button to search through the tracks backward.  
Press the TRACK+ button to search through the tracks forward.
- **▶|| button**  
When a CD is playing, this button pauses the play.  
Press the same button again to start play again.

## Disc Changer Mode

- **Number/ letter entry buttons**  
Used to specify the track (disc) number used in direct track (disc) searches.  
Use to enter letters during disc name preset.
- **TRACK buttons**  
Press the TRACK- button to search through the tracks backward.  
Press the TRACK+ button to search through the tracks forward.  
Use to move the cursor while entering disc name.
- **DISC buttons**  
Press the DISC- button to search through the discs backward.  
Press the DISC+ button to search through the discs forward.  
Select numbers and symbols while entering disc name.
- **▶|| button**  
When a disc is playing, this button pauses the play.  
Press the same button again to start play again.
- **OK buttons**  
During disc name input, stores the already input data in memory and ends the input mode.  
Selects disc during the disc name preset play mode.
- **DNPP button**  
Enters and cancels the Disc Name Preset Play mode.

## Tuner features (See page 8)

### Tuning

You can choose from three tuning modes: auto seek, preset station seek, and manual. The "Auto1" indicator lights up when auto seek tuning is selected, and the "Auto2" indicator lights when preset station seek tuning is selected.

#### Selecting Tuning Mode:

Press the AUTO button.

Each time you press the AUTO button, the mode switches as follows.

↓  
AUTO 1 (Auto Seek Tuning)  
↓  
AUTO 2 (Preset Station Seek Tuning)  
↓  
MANUAL (Manual Tuning)

#### Tuning:

- 1 Press the TUN button to turn the radio on.
- 2 Press either the FM or AM button to select the band.  
Each time you press the FM button, the band switches between the FM1, FM2 and FM3 (which are used for groups of preset stations).  
Press the AM button to select the AM band.
- 3
  - **Auto Seek Tuning**  
Press the ►► button to seek higher frequencies.  
Press the ◄◄ button to seek lower frequencies.
  - **Preset station seek tuning**  
Press the ►► button to move to the next preset station (i.e., the one with the next highest number), and the ◄◄ button to move to the last preset station (i.e., the one with the next lowest number).
  - **Manual Tuning**  
Press the ►► button to increase the frequency by one step.  
Press the ◄◄ button to decrease the frequency by one step.

#### NOTE

The ST indicator lights up when stereo broadcasts are being received.

## Station Preset Memory

Store the frequency of a station. You can then recall that station with a single touch of a button.

- 1 Select the band/station that you want to have stored.
- 2 Press the button (#1-6) that you want to use for the station, for at least two seconds.  
The button number blinks once in the display to indicate that the data has been stored.

### Recalling a Preset Station:

Press the preset station button (#1-6) for the desired station. The number of the recalled station is displayed.

#### NOTE

You can store six stations in each of the FM1, FM2, FM3, and AM bands.

## Auto Memory Entry

You can automatically store all the receivable frequencies in the band currently being listened to, and then recall them with the touch of a button later. This function is especially useful when you are travelling and do not know what stations are available. Up to six frequencies can be stored this way.

- 1 Select the band for which you want to store stations.
- 2 Press the AME button for at least two seconds to start auto memory entry.  
The numbers of the preset station buttons are shown in order. When all the stations in a certain band are stored in the preset memory, the auto memory entry stops. The tuner then plays the last station received.

### Recalling a Preset Station:

Press the preset station button (#1-6) for the desired station. The number of the recalled station is displayed.

## Clean Reception System Circuit (CRSC)

Temporarily have reception switched from stereo to mono to reduce multi-path noise when listening to the FM station. The factory default for this function is ON.

### Turning CRSC On/Off:

Press the CRSC button for at least one second to turn the function on/off. "CRSC ON" is displayed when CRSC is on.

#### NOTE

Strong electrical fields (such as from power lines) may cause unstable sound quality when CRSC is turned on. In such a situation, turn it off.

*Function of Remote (See page 10)*

## Direct Access Tuning

When you know the frequency of the station that you want to listen to, you can input it directly for quick access.  
(Function of remote)

- 1 Select the band by pressing the FM or AM button.
- 2 Press the DIRECT button.  
In the display, "—" blinks for 10 seconds.  
If you make no input in the 10-second period, direct access tuning is automatically canceled.
- 3 Enter the frequency of the desired station while the display is blinking.  
If you want to listen to an FM station at 92.1 MHz, for example, press 0, 9, 2, and 1.  
If you want to listen to an AM station at 810 kHz, for example, press 0, 8, 1, and 0.

#### NOTE

When a frequency which cannot be received is input, this frequency is not verified and operation returns to the original frequency input mode.

### Canceling Direct Access Tuning:

Press the DIRECT button again.

## Station Name Preset (SNPS)

You can assign names to radio stations with the Station Preset Memory. Up to 25 FM stations and 8 AM stations can be assigned names.

- 1 Adjust the frequency to the station whose name you want to enter.
- 2 Press the NAME.S button for at least two seconds.  
"NAME SET" is displayed once the station name preset mode is entered.  
The cursor will blink in the position where letters are entered.
- 3 Press either the ◀◀ or ▶▶ button to move the cursor to the desired position.  
The ◀◀ button moves the cursor to the left, and the ▶▶ button to the right.  
You can also move the cursor left or right by pressing the ◀◀ or ▶▶ buttons, respectively, on the remote.
- 4 Press the FM or AM button to display the desired character.  
Besides the alphabet (capital letters only) and numerals, you can choose the following characters: /, +, -, \*, =, <, >, [ and ].

### **NOTE** Direct Input

Direct input can be made of letters (alphabetical) with the letter entry buttons on the remote.

Example: Use the following table to enter the name "DANCE".

| Character | Button to press | # Times pressed |
|-----------|-----------------|-----------------|
| "D"       | #3              | 1               |
| "A"       | #2              | 1               |
| "N"       | #6              | 2               |
| "C"       | #2              | 3               |
| "E"       | #3              | 2               |

- 5 Continue steps 3 and 4 until all the characters are chosen for the name.

### **NOTE**

You can enter up to 8 characters for each name.

- 6 • Assigning Names  
Press the NAME.S button on the unit or the OK button on the remote.  
The name of the station is stored in memory, and the Station Name Preset mode ends.
- Assigning Name and Storing Frequency with Station Preset Memory  
Hold down the desired preset button for at least two seconds.  
The name of the station is stored and the frequency for the current station is stored in the selected preset button. The Station Name Preset mode ends.  
Also, if you make no input for 10 seconds, the name will be stored up to the point that you have entered, and the mode ends.

### **NOTE**

- You can assign names to up to 25 FM stations and 8 AM stations. If you try to enter more than that, the station name stored the earliest will be the first one erased.  
However, the station names stored in the preset button will be retained in the memory preferentially.
- All the station names will be erased if you press the RESET button.
- If you want to change the name of a station, first display the name of the station (following steps 1 and 2 above), then change the letter(s) that you want by following steps 3 and 4.




Function of Remote (See page 10)

## Station Name Preset Play (SNPP)

You can search for the station for any station if its name has been preset using Station Name Preset.

- 1 Press the DNPP button on the remote.  
"SNP PLAY" will be displayed once the station name preset play mode is entered.  
The names of the stations preset in the band currently listened to are displayed for five seconds each. The display band switches in the following order:



Each time you press the ►► button, the station display switches in the forward direction.

Each time you press the ◄◄ button, the station display switches in the reverse direction.

Stations whose names have not been stored will be displayed as frequencies.

### **NOTE** Changing the Displayed Band

Pressing the FM button switches between the FM1, FM2, FM3 and AM displays, in that order.

Pressing the AM button switches between the display in the reverse direction.

- 2 **Once the name is displayed for the station you want to listen to**

Press the OK button.

Reception starts of the displayed station, and the station name preset play mode ends.

### **Canceling mode during input:**

Press the DNPP button.

The station name preset play mode is canceled.

## CD player features (See page 9)

### Playing CDs

#### **Play:**

Press the CD button to slide open the faceplate, showing the CD (insertion) slot. Holding the CD with the labeled side facing up, insert it in the slot. The faceplate will show the control panel, and the CD will start playing.

The ► indicator lights up when a CD is being played.

#### **Playing CDs Already Inserted:**

The ►◄ indicator will light when a CD has been inserted.

Press the CD button to start play.

#### **Pausing and Restarting CD Play:**

Press the CD button to make the disc pause.

The || indicator lights up.

Press the same button again to start play again.

#### **Stop / Eject:**

Press the EJECT button for at least one second to stop CD play. The faceplate will slide to eject the CD.

Press the CD, CH or TUN button to show the control panel.

### **CAUTION**

- Do not attempt to insert a CD into the slot if another one is already there.
- The unit can only play 5 in. CDs. If you insert a 3 in. CD, it will get stuck inside and can cause the unit to malfunction.

### **NOTE**

- The sound will be temporarily muted while the faceplate is moving.
- The only buttons that will work during the eject state are the CD, CH, and TUN buttons, as well as the volume control button.
- When you load a CD and eject it right away, the next time you try to insert the CD may not load. In such a situation, take the CD out for a moment and then reinsert it.
- The faceplate is a piece of precision equipment. Do not keep the faceplate open and subject it to excessive force during its opening and moving.


## CD player features (See page 9)

### Switching Display for CDs

Switch the display that appears while discs are playing.

#### Switching Display for CDs:

Each time you press the DISP button, the display during CD play switches as follows:



### Fast Forwarding and Reversing Disc Play

#### Fast Forwarding Disc Play:

Hold down on the ►► button.

Release your finger to play the disc at that point.

#### Reversing Disc Play:

Hold down on the ◀◀ button.

Release your finger to play the disc at the point.

### Track Search

Search forward or backward through the tracks on the disc until you reach the one that you want to listen to.

#### Making a Reverse Track Search:

Press the ◀◀ button to display the desired track number.

Press once to search back to the beginning of the current track, twice to search back to the beginning of the previous track, and so forth.

Play starts at the beginning of the displayed track number.

#### Making a Forward Track Search:

Press the ►► button to display the desired track number.

Press once to fast forward to the next track, twice to fast forward to the track after that, and so forth.

Play starts at the beginning of the displayed track number.

## Function of Remote (See page 10)

### Direct Track Search

Using the remote, directly input the track number that you want to listen to.

- 1 Using the number buttons on the remote, input the number of the track that you want to listen to.  
The selected track number will blink in the display for 10 seconds.  
If you make no further input in the 10-second period, the number entry mode will automatically be canceled.
- 2 Press either the TRACK+ or TRACK- button while the track number is blinking.  
The track starts playing.

#### Canceling Direct Track Search While It Is Operating:

Press the ►|| button.

#### NOTE

You cannot use the direct track search function while doing track scans or using random play.

### Track Repeat

Repeat playing the track currently being listened to.

#### Turning Repeat Play On/Off:

Press the REP button to switch repeat play on and off.

The REP indicator lights up when repeat play is turned on.

The track number currently being heard blinks in the display.

#### NOTE

Repeat play is canceled when you stop playing the disc.

**Track Scan**

**Successively play the beginning of each track on a disc until you find the track that you want to listen to.**

**Turning Track Scan On/Off:**

Press the SCAN button to switch track scan on and off.  
The SCN indicator lights up when track scan is turned on.  
The first 10 seconds of each track will be played, in order.  
The track number currently being heard blinks in the display.

**Stopping to Listen to the Track Being Scanned:**

Press the SCAN button again to stop the scan and keep on listening to a track normally.

**NOTE**

- Track scan is canceled when you stop playing a disc.
- Track scan only scans each track on a disc once.

**Random Play**

**Play all the tracks on the current disc in random order.**

- 1 Press the RDM button to switch random play on and off.  
The RDM indicator lights up when random play is turned on.  
The track number will change over and over in the display as the next track is being selected.  
When the track has been selected, play will begin.  
The selected track number blinks in the display as it is being played.
- 2 To change the track being heard, press the ►► button.  
Another track will be selected and played.

**NOTE**

Random play is canceled when you stop playing a disc.

**Playing Discs Using a Disc Changer****Playing Discs:**

Press the CH button.

The disc indicator lights up during disc changer mode.

When one disc has finished playing its last track, the next disc in the changer will start playing. When the last disc in the changer has finished, the player will return to the first disc and start playing it.

Disc #10 is displayed as "0".

**Switching Between Disc Changers:**

When two disc changers are connected to the unit, press the CH button for at least one second to switch from one to the other.

**NOTE**

The KCA-S200, which is sold separately, must be installed when two disc changers are connected. When the KDC-C810 is the directly connected disc changer (disc changer 1), two units may be controlled even without the KCA-S200.

**Pausing and Restarting Disc Play:**

Press the CH button to make the disc pause.

Press the same button again to start play again.


## Disc changer control features (See page 9)

### Switching Display for Discs

Switch the display that appears while discs are playing.

#### Switching Display for Discs:

Each time you press the DISP button, the display during disc play switches as follows:



#### NOTE

- You can give names to discs through the presetting disc name function (see p. 23).
- If you try to display the name of a disc that doesn't have one, "NO NAME" is displayed instead.
- When the source you are listening to is finished or interrupted (ex. switching the ignition position, changing the sources), the initial display will return.

### Fast Forwarding and Reversing Disc Play

#### Fast Forwarding Disc Play:

Hold down on the ►► button.

Release your finger to play the disc at that point.

#### Reversing Disc Play:

Hold down on the ◀◀ button.

Release your finger to play the disc at the point.

#### NOTE

You cannot use reverse play between tracks when listening to an MD on the MD changer. Instead, the reverse play function is canceled when it reaches the beginning of a track, at which point normal play will automatically resume.

### Track Search

Search forward or backward through the tracks on the disc until you reach the one that you want to listen to.

#### Making a Reverse Track Search:

Press the ◀◀ button to display the desired track number.

Press once to search back to the beginning of the current track, twice to search back to the beginning of the previous track, and so forth.

Play starts at the beginning of the displayed track number.

#### NOTE

Pressing the ◀◀ button while listening to track 1 will only search back to the beginning of that track. The reverse search is not "recycled" to the last track on the disc.

#### Making a Forward Track Search:

Press the ►► button to display the desired track number.

Press once to fast forward to the next track, twice to fast forward to the track after that, and so forth.

Play starts at the beginning of the displayed track number.

#### NOTE

You cannot make a forward track search when listening to the last track on a disc.

## Disc Search

Search forward or backward through the discs in a disc changer.

### **Making a Reverse Disc Search:**

Press the DISC- button to display the desired disc number. Each time the button is pressed, the displayed disc number decreases by one. Play starts at the beginning of the displayed disc.

### **Making a Forward Disc Search:**

Press the DISC+ button to display the desired disc number. Each time the button is pressed, the displayed disc number increases by one. Play starts at the beginning of the displayed disc.

#### **NOTE**

"LOAD" is displayed when discs are being exchanged on the disc changer.

## Track / Disc Repeat

Repeat playing the track or the disc currently being listened to.

### **Turning Repeat Play On/Off:**

Press the REP button to switch repeat track/disc play on and off as follows:

Track Repeat ON

Disc Repeat ON

Track/Disc Repeat OFF

The REP indicator lights up when repeat play is turned on. The track number blinks in the display when track repeat is on. The disc number blinks in the display when disc repeat is on.

#### **NOTE**

Repeat play is canceled when you stop playing the disc.

## Random Play

Play all the tracks on the current disc in random order.

- 1 Press the RDM button to switch random play on and off. The RDM indicator lights up when random play is turned on. The track number will change over and over in the display as the next track is being selected. When the track has been selected, play will begin. The selected track number blinks in the display as it is being played.

#### **NOTE**

When all the tracks on a certain disc have been played using random play, the next disc on the changer will start playing using the same function.

- 2 To change the track being heard, press the ►► button. Another track will be selected and played.

#### **NOTE**

Random play is canceled when you stop playing a disc.

## Disc changer control features (See page 9)

### Magazine Random Play

Play the tracks on all the discs in the disc changer in random order.

- 1 Press the M.RDM button to switch magazine random play on and off.  
The RDM indicator lights up when magazine random play is turned on.  
The disc and track numbers will change over and over in the display as the next track is being selected.  
When the disc/track has been selected, play will begin.  
The selected disc/ track number blinks in the display as it is being played.

#### NOTE

This function is not available with the following models:  
KDC-C200/C300/C400/C301/C401

- 2 To change the track being heard, press the ►► button.  
Another disc/track will be selected and played.

#### NOTE

- Magazine random play is canceled when you stop playing a disc.
- The time needed for random selection depends on the number of discs loaded in the disc magazine.

### Track Scan

Successively play the beginning of each track on a disc until you find the track that you want to listen to.

#### Turning Track Scan On/Off:

Press the SCAN button to switch track scan on and off.  
The SCN indicator lights up when track scan is turned on.  
The first 10 seconds of each track will be played, in order.  
The track number currently being heard blinks in the display.

#### Stopping to Listen to the Track Being Scanned:

Press the CH or SCAN button again to stop the scan and keep on listening to a track normally.

#### NOTE

- Track scan is canceled when you stop playing a disc.
- Track scan only scans each track on a disc once.

### Disc Scan

Successively play the beginning of each disc on a changer until you find the one that you want to listen to.

#### Turning Disc Scan On/Off:

Press the D.SCN button to switch disc scan on and off.  
The SCN indicator lights up when disc scan is turned on.  
The first 10 seconds of each disc will be played, in the order they are loaded on the changer.  
The disc number currently being heard blinks in the display.

#### Stopping to Listen to the Disc Being Scanned:

Press the CH or D.SCN button again to stop the scan and keep on listening to the disc normally.

#### NOTE

- Disc scan is canceled when you stop playing a disc.
- Disc scan only scans each disc on the changer once.
- "LOAD" is displayed when discs are being exchanged on the disc changer.

## Presetting Disc Names

Store the names of discs to be displayed when played.

- 1 Play the disc whose name you want to preset.

### NOTE

- This function is not available for disc changers that do not feature the Disc Name Preset function.
- This procedure is not to be used to store the disc and track titles for MDs that you record.

- 2 Press the NAME.S button for at least two seconds. "NAME SET" is displayed and the disc name preset mode is entered.

The cursor blinks in the position where character input can be made.

- 3 Press either the ◀◀ or ▶▶ button to move the cursor to the desired position.

The ◀◀ button moves the cursor to the left, and the ▶▶ button to the right.

You can also move the cursor left or right by pressing the TRACK+ or TRACK- buttons, respectively, on the remote control.

- 4 Press the DISC+ or DISC- button to display the desired character.

Besides the alphabet (capital letters only) and numbers, you can choose the following characters: /, +, -, \*, =, <, >, { and }.

### NOTE Direct Input

For units with KDC-C810, KDC-C710, KDC-C660 or KDC-C660C attached, you can directly input letters using the number/letter entry buttons on the remote.

Example: Use the following table to enter the name "DANCE".

| Character | Button to press | # Times pressed |
|-----------|-----------------|-----------------|
| "D"       | #3              | 1               |
| "A"       | #2              | 1               |
| "N"       | #6              | 2               |
| "C"       | #2              | 3               |
| "E"       | #3              | 2               |

- 5 Continue steps 3 and 4 until all the characters are chosen for the name.

### NOTE

You can enter up to eight characters for each name.

- 6 Press either the NAME.S button on the main unit or the OK button on the remote.

The disc name is stored and the disc name preset mode is canceled.

If you make no entry in a 10-second period, the name will be stored with the characters input so far.

### NOTE

- With the CD changer, you can only store names for up to 100 CDs (The KDC-C710, KDC-C660 and KDC-C660C disc changers can store names for up to 50 discs.), and with the MD changer, you can only store names for up to 30 MDs. If you store the name for a 101st (51st) CD or 31st MD, the first name stored for the type of disc will be erased automatically.
- Discs are identified by their total length and number of tracks. If another disc happens to have the same specifications as one that you have already stored a name for, the name will be displayed for it, too.
- If you want to change the name of a disc, repeat steps 1 and 2 to display the name, and then repeat steps 3 and 4 to input the changes.
- Pressing the reset button does not erase the disc names stored in a disc changer.

### Direct Track Search

**Using the remote, directly input the track number that you want to listen to.**

- 1 Using the number buttons on the remote, input the number of the track that you want to listen to.  
The selected track number will blink in the display for 10 seconds.  
If you make no further input in the 10-second period, the number entry mode will automatically be canceled.
- 2 Press either the TRACK+ or TRACK- button while the track number is blinking.  
The track starts playing.

**Canceling Direct Track Search While It Is Operating:**

Press the ►|| button.

#### NOTE

You cannot use the direct track search function while doing track or disc scans or using random or magazine-random play.

### Direct Disc Search

**Using the remote, directly input the disc number that you want to listen to.**

- 1 Using the number buttons on the remote, input the number of the disc that you want to listen to.  
The selected disc number will blink in the display for 10 seconds.  
If you make no further input in the 10-second period, the number entry mode will automatically be canceled.

#### NOTE

- Input "0" to select disc 10.
  - If you input more than two numbers all at once, a search will be made only of the last number input.
- 2 Press either the DISC+ or DISC- button while the number inputted is blinking.

The disc starts playing.

**Canceling Direct Disc Search While It Is Operating:**

Press the ►|| button.

### Disc Name Preset Play (DNPP)

**If you have preset the name of a disc that you want to listen to in the disc changer, you can look for it by name and start playing it.**

- 1 Press the DNPP button on the remote.  
"DNP PLAY" will appear in the display, and the disc name preset play mode is entered.  
The names of all the discs in the disc changer will appear successively in the display for five seconds each. Discs whose names have not been preset will appear as "NO NAME" in the display.

#### NOTE

Discs in the disc changer that have never been played before will appear as "NO ACCES" when the disc names are displayed. When you cannot identify a disc because of the "NO ACCES" display after inserting a disc magazine, try playing it using the disc scan or a similar function to display the disc name.

**Rapid display (forward / reverse):**

Press the DISC+ or DISC- button.  
Pressing the DISC+ button will rapidly display the preset names/disc titles in order.  
Pressing the DISC- button will rapidly display the preset names/disc titles in reverse order.

- 2 **When the name appears for the disc you want to play**

Press the OK button.

The disc whose name is displayed will be recalled, and the disc name preset play (DNPP) mode will end.

**To cancel DNPP mode:**

Press the DNPP button.


The disc name preset play (DNPP) mode will be canceled.



## Audio Control Setting

**Adjust various parameters of sound quality.**

- 1 Press the AUD button to enter the control mode.
- 2 Press either the FM or AM button.  
Each time the button is pressed, the adjustment mode will change as follows:  
Pressing the FM button advances the display, and pressing the AM button reverses it.



### **NOTE** Source tone memory

Each source (CD, FM, AM and disc changer) has its own memory in which to store the bass and treble tone settings. The settings made for a particular source are recalled automatically whenever you use that source (for example, FM mode uses the tone settings made for FM, AM for AM, etc.).


- 3 Press the ◀▶ button.  
Look at the table to adjust the mode being displayed.
- 4 Press the AUD button to end the control mode.

### **NOTE** Setting the high-pass filter (KDC-8007 only)

You can separately set the high-pass filter for front and rear output, including preouts. The high-pass filter works except during non-fading preout when switching to non-fading. The factory default settings for front output and rear output are "through."

## Table of Audio Control Setting

| Adjustment mode (Display) | Operation of Audio control button |                           |
|---------------------------|-----------------------------------|---------------------------|
|                           |                                   |                           |
| Bass ("BAS")              | Bass decreased.                   | Bass increased.           |
| Treble ("TRE")            | Treble decreased.                 | Treble increased.         |
| Balance ("BAL")           | Left channel emphasized.          | Right channel emphasized. |
| Fader ("FAD")             | Rear channel increased.           | Front channel increased.  |



**KDC-8007 only**

### **NOTE**

The balance of the non-fading sound cannot be adjusted.

## Other features (See page 10)

### Clock Display

#### Display the time.

##### Switching to Time Display:

Keep pressing the CLK button until the clock is displayed.

### Adjusting Time

#### Adjust the time.

- 1 When the time is not displayed, first press the CLK button to display the time.
- 2 While holding down the CLK button, press the ◀◀ or ▶▶ buttons to adjust the time.  
The ◀◀ button adjusts the hour and the ▶▶ button adjusts the minutes.

#### NOTE

Do not press the CLK button for two seconds or more, as it will change to the name preset mode.

### Selectable Illumination

You can switch the color of the button illumination between green and amber.

##### Switching the illumination:

Press the ILLUM button for at least one second to switch between amber and green.

### Valet Mode

The faceplate will not appear as long as the switch is not changed, preventing tampering with the unit when you let someone else drive the car.

##### Connecting Valet Cable:

Connect the pink valet cable to the ON/OFF switch, while

grounding the other side of the switch.

#### NOTE

- Make sure the unit is grounded properly, or else the unit may not operate correctly.
- We suggest you install the valet cable in a place where the ON/OFF switch is difficult to find.

##### Turning Valet Mode on:

- 1 Turn the ON/OFF switch on.
- 2 Turn the power off either by turning off the ignition or by pressing the CLOSE/PWR OFF button for at least one second. The valet function will turn on, and the faceplate will reverse to hide the control panel. In this condition, the unit cannot be turned on until the valet function is turned off.

#### NOTE

You can reverse the order of steps 1 and 2 and still activate the valet mode.

##### Canceling Valet Mode:

Turn the ON/OFF switch off.

Turn the ignition on, or press "the touch-sensitive spot" at the rear of the faceplate (see p.11) to make the control panel appear.

*Function of the KDC-800*

### Non-fading Preout

**Switch the front preout to non-fading. When you switch to non-fading, you can adjust the volume separately.**

##### Switching front preout:

- 1 Press the TUN button repeatedly and switch the display to "ALL OFF" to enter the standby mode.
- 2 Press the #2 button for at least three seconds to switch the preout from front to non-fading or vice versa.  
"NON-FAD" is displayed when non-fading is selected.

#### NOTE

- When the front preout is switched to "non-fading", the level difference between this preout and the rear preout and front and rear channels can be adjusted. The "non-fading" preout

level remains the same while the rear preout and front and rear channel levels decrease by the value set for the "non-fading" feature (see p. 25).

- You cannot use the high-pass filter with non-fading preout.

### Turning non-fading output On/Off:

Press the NF button for at least one second to set the function ON or OFF.

"NF ON" is displayed when the non-fading output is set ON.

#### NOTE

If the preout is switched to non-fading, the non-fading preout is automatically set ON.

## Security Code

**When the battery is removed from the unit's power switch, you cannot turn on the unit again unless the preset security code is input. This function helps prevent theft.**

#### NOTE

You must follow steps 1 to 7 to be able to use the Code Security function. Turning off the power during the procedure will deactivate the security code setting. You cannot turn off the function after having completed these steps.

- 1 Select the four digits to use in your security code.

#### NOTE

The four-digit security code is very important, as you will need it to turn the unit on again when the code security function is on. Choose the number carefully and do not forget it (write it down and keep it separately in a safe place).

- 2 Press the TUN button repeatedly and switch the display to "ALL OFF" to enter the standby mode.
- 3 Press button #6 for at least three seconds. "ENTER" will appear in the display for one second, indicating the code setting mode has been entered. When "CODE" appears in the display, you can start inputting the code.

- 4 Press the preset button and enter the security code that you have selected in step 1.  
Example: Use "3510" as the security code.

| Step | Button to press | # Times pressed | Display |
|------|-----------------|-----------------|---------|
| 1    | #1              | 4               | "3"     |
| 2    | #2              | 6               | "5"     |
| 3    | #3              | 2               | "1"     |
| 4    | #4              | 1               | "0"     |

- 5 Press the NAME.S button for at least three seconds. The security code will be set. "RE-ENTER" will appear in the display for one second, asking you to enter the code once again for confirmation. When "CODE" appears in the display, you can start inputting the code.
- 6 Press the Preset button and input the security code again.
- 7 Press the NAME.S button again for at least three seconds. "APPROVED" will appear in the display, with the code security function turning on. From this point on, if the unit is disconnected from the battery, the security code must be entered the first time that the unit's power is turned on. "CODE" will appear in the display, asking you to input the code.

#### NOTE

If you input an incorrect security code, the display ask you once more to input the correct one. Follow the procedure in step 3 above.










### If you press the RESET button or remove the battery:

The first time you turn the unit on again, "CODE" will appear in the display, asking you to input the security code. Repeat steps 6 and 7 above, and input the security code. You can start operating the unit again when "APPROVED" appears in the display. If you enter the incorrect code, the power will turn off. Enter the correct code to turn the unit on.

## Accessories

## External view

## Number of items

|   |   |        |
|---|---|--------|
| ① |    | .....1 |
| ② |    | .....1 |
| ③ |    | .....2 |
| ④ |    | .....1 |
| ⑤ |    | .....2 |
| ⑥ |    | .....2 |
| ⑦ |    | .....1 |
| ⑧ |   | .....1 |
| ⑨ |  | .....1 |

**▲CAUTION**

Do not use any accessories other than those provided with your unit. If you use other accessories, you may damage the unit.


## Installation Procedure

1. To prevent a short circuit, remove the key from the ignition and disconnect the  $\ominus$  battery.
2. Make the proper input and output wire connections for each.
3. Connect the speaker wires of the wiring harness.
4. Connect the wiring harness wires in the following order: ground, battery, ignition.
5. Connect the wiring harness connector to the unit.
6. Install the unit in your car.
7. Reconnect the  $\ominus$  battery.
8. Press "the touch-sensitive spot" at the rear of the faceplate (p.11) to make the faceplate control panel appear. Then press Reset button.

**▲CAUTION**

- If your car's ignition does not have an ACC position, connect the ignition wires to a power source that can be turned on and off with the ignition key. If you connect the ignition wire to a power source with a constant voltage supply, as with battery wires, the battery may die.
- If the console has a lid, make sure to install the unit so that the faceplate will not hit the lid when closing and opening.
- If the fuse blows, first make sure the wires aren't touching and cause a short circuit, then replace the old fuse with one with the same rating.
- Do not let unconnected wires or terminals touch metal on the car or anything else conducting electricity. To prevent a short circuit, do not remove the caps on the ends of the unconnected wires or the terminals.
- Connect the speaker wires correctly to the terminals to which they correspond. The unit may be damaged or fail to work if you share the  $\ominus$  wires or ground them to any metal part in the car.
- After the unit is installed, check whether the brake lamps, blinkers, wipers, etc. on the car are working properly.
- Insulate unconnected wires with vinyl tape or other similar material.
- Some disc changers need conversion cords for connection. See the section on "Safety Precautions" for details.

# Connecting Wires to Terminals




## WARNING

If you connect the ignition wire (red) and the battery wire (yellow) to the car chassis (ground), you may cause a short circuit, that in turn may start a fire. Always connect those wires to the power source running through the fuse box.

## CAUTION

When only two speakers are being connected to the system, connect the connectors either to both the front output terminals or to both the rear output terminals (do not mix front and rear). For example, if you connect the ⊕ connector of the left speaker to a front output terminal, do not connect the ⊖ connector to a rear output terminal.

## ■ Installation




### NOTE


Make sure that the unit is installed securely in place. If the unit is unstable, it may malfunction (for example, the sound may skip).

## ■ Removing the hard rubber frame

- 1 Insert the removal tool⑨ deeply with the cut placed to the right to remove the upper locks at an angle as shown below.



- 2 Engage the catches on the removal tool③ and remove the two locks on the lower level, leaving the removal tool⑨ inserted on the upper level. Use the removal tool facing the side covered with the protective sheet to the faceplate. Lower the frame and pull it forward as shown in the figure.





### NOTE

You will feel (not hear) a click when the tabs lock securely.

## ■ Installing Radio Bracket in Japanese-made Cars (J-Cars)

On the factory-installed radio bracket, flatten all the tabs or holes that are not flush (except those used for screws), using a hammer or similar utensil.




Accessory⑦  
J-Car Bracket  
(follow indications for L/R)

Factory-installed  
Radio Bracket


Factory trim bezel

Factory-installed  
Radio Bracket

After aligning the J-Car bracket with the factory-installed radio bracket, tighten the screws.



Accessory⑥  
for Nissan car




Accessory⑧  
for Toyota car

### ⚠ CAUTION

Damage to the unit will result from using screws other than those provided.

Accessory⑧  
J-Car Trim Plate  
(place thick part on bottom)

Once you have affixed the factory-installed radio bracket with the screws, use a standard-tipped screwdriver (not Philips) or similar utensil to pry the tabs of the J-Car bracket to make them fit into the holes in the factory-installed radio bracket (depending on the car make).



N ... Nissan car  
T ... Toyota car

### Installing in Toyota cars


If necessary, neatly cut the frame of the trim plate with an engraving knife or similar utensil, following the inner grooves on the top and bottom of the plate.

### NOTE


You may have to cut the factory trim bezel as well if it interferes with the movement of the face plate.

## ■ Removing the Unit

- 1 Refer to the section "Removing the hard rubber frame" (p.30) and then remove the hard rubber frame.
- 2 Remove the hex head machine screw with washer (M4×8) on the back panel.
- 3 Insert the two removal tools at an angle and push them deeply into the slots on each side, as shown.




- 4 Push downward on the left-hand tool and the upward on the right-hand tool, as shown, and pull the unit toward you until it is halfway out. The unit may drop if you pull it out completely.



### ▲CAUTION

Be careful to avoid injury from the catch pins on the removal tool.

- 5 Pull the unit all the way out with your hands, being careful not to drop it.





## Troubleshooting Guide

What might seem to be a malfunction in your unit may just be the result of slight misoperation or miswiring. Before calling service, first check the following table for possible problems.

| PROBLEM   | POSSIBLE CAUSE  | SOLUTION  |
|---|---|---|
| The power does not turn on.                           | The fuse has blown.   | After checking for short circuits in the wires, replace the fuse with one with the same rating.                       |
| No sound can be heard, or the volume is low.          | Attenuator is turned on.  | Turn off Attenuator.  |
|   | The fader or balance settings are set all the way to one side.      | Reset the fader or balance settings.  |
|   | The input/output wires or wiring harness are connected incorrectly. | Reconnect the input/output wires or the wiring harness correctly. See the section on "Connecting Wires to Terminals". |
| Nothing happens when the buttons are pressed.         | The computer chip in the unit is not functioning normally.          | Press the reset button on the unit (see p. 6).  |
| The sound quality is poor or distorted.               | One of the speaker wires is being pinched by a screw in the car.    | Check the speaker wiring.   |
|   | The speakers are not wired correctly.                               | Reconnect the speaker wires so that each output terminal is connected to a different speaker.                         |
| Radio reception is poor.                              | The car antenna is not extended.                                    | Pull the antenna out all the way.   |
|   | The antenna control wire is not connected.                          | Connect the wire correctly, referring to the section on "Connecting Wires to Terminals".                              |
| The memory is erased when the ignition is turned off. | The battery wire has not been connected to the proper terminal.     | Connect the wire correctly, referring to the section on "Connecting Wires to Terminals".                              |
| The faceplate does not open or close.                 | The ambient temperature is too low.                                 | Warm up your car.   |
|   | The valet mode is ON.   | Turn off the valet mode.  |

| PROBLEM                              | POSSIBLE CAUSE                 | SOLUTION   |
|--------------------------------------|--------------------------------|--|
| A CD ejects as soon as it is loaded. | The CD is upside-down.         | Load the CD with the labeled side up.                                |
|                                      | The CD is quite dirty.         | Clean the CD, referring to the section on "Cleaning CDs" (see p. 7). |
| The sound skips on a CD.             | The CD is scratched or dirty.  | Clean the CD, referring to the section on "Cleaning CDs" (see p. 7). |
| A track will not play.               | Random play has been selected. | Turn off random play.  |

## Disc Changer

| PROBLEM  | POSSIBLE CAUSE  | SOLUTION   |
|--|---|--|
| The disc changer mode cannot be selected.                                      | No cable has been connected to the disc changer input terminal on the unit. | Connect the cable to the disc changer input terminal on the unit.  |
| The specified disc does not play, but another one plays instead.               | The specified CD is quite dirty.  | Clean the CD.  |
|  | The CD is upside-down.  | Load the CD with the labeled side up.  |
|  | The disc is loaded in a different slot from that specified.                 | Eject the disc magazine and check the number for the specified disc.   |
|  | The disc is severely scratched.   | Try another disc instead.  |
| The sound skips.   | Something is touching the disc changer.                                     | Remove whatever is touching it.  |
|  | The CD is scratched or dirty.   | If skipping happens at the same place when the car is stopped, something with the CD is wrong. Clean the CD. |
| The display shows that the changer is being played, but no sound can be heard. | The computer chip in the unit is not functioning normally.                  | Press the reset button on the unit (see p. 6).   |
| The specified track will not play.   | Random play or magazine random play has been selected.                      | Turn off random play or magazine random play.  |

**The following messages are displayed when certain problems are occurring in your system. Take the recommended actions.**

- |                      |   |
|----------------------|---|
| <b>EJECT</b>         | No disc magazine has been loaded in the changer. The disc magazine is not completely loaded.<br>⇒ Load the disc magazine properly.  |
| <b>NO DISC</b>       | No disc has been loaded in the disc magazine.<br>⇒ Load a disc into the disc magazine.  |
| <b>E-04</b>          | No disc has been loaded in the disc magazine.<br>⇒ Load a disc into the disc magazine.<br>The CD is quite dirty. The CD is upside-down. The CD is scratched a lot.<br>⇒ Clean the CD and load it correctly.   |
| <b>BLANK</b>         | Nothing has been recorded on the MD.<br>⇒ The next MD will automatically be played.   |
| <b>NO TRACK</b>      | No tracks are recorded on the MD, although it has a title.<br>⇒ The next MD will automatically be played.   |
| <b>E-77<br/>E-99</b> | The unit is malfunctioning for some reason.<br>⇒ Press the reset button on the unit. If the "E- 77", "E- 99" code does not disappear, consult your nearest service center.  |
| <b>HOLD</b>          | The protective circuit in the unit activates when the temperature inside the automatic disc changer exceeds 60°C (140°F), stopping all operation.<br>⇒ Cool down the unit by opening the windows or turning on the air conditioner. As the temperature falls below 60°C (140°F), the disc will start playing again. |

**Specifications subject to change without notice.**

**FM tuner section**

|                                    |                                    |
|------------------------------------|------------------------------------|
| Frequency range (200 kHz space)    | 87.9 MHz – 107.9 MHz               |
| Usable sensitivity (S/N = 30dB)    | 9.3dBf (0.8 $\mu$ V/75 $\Omega$ )  |
| Quieting Sensitivity (S/N = 50dB)  | 15.2dBf (1.6 $\mu$ V/75 $\Omega$ ) |
| Frequency response ( $\pm$ 3.0 dB) | 30 Hz – 15 kHz                     |
| Signal to Noise ratio (MONO)       | 75 dB                              |
| Selectivity ( $\pm$ 400 kHz)       | $\geq$ 80 dB                       |
| Stereo separation (1 kHz)          | 40 dB                              |

**AM tuner section**

|                                 |                          |
|---------------------------------|--------------------------|
| Frequency range (10 kHz space)  | 530 kHz – 1700 kHz       |
| Usable sensitivity (S/N = 20dB) | 28 dB $\mu$ (25 $\mu$ V) |

**CD player section**

|                                   |                             |
|-----------------------------------|-----------------------------|
| Laser diode                       | GaAlAs ( $\lambda$ =780 nm) |
| Digital filter (D/A)              | 8 Times Over Sampling       |
| D/A Converter                     | 1 Bit                       |
| Spindle speed                     | 500 – 200 rpm (CLV)         |
| Wow & Flutter                     | Below Measurable Limit      |
| Frequency response ( $\pm$ 1 dB)  | 10 Hz – 20 kHz              |
| Total harmonic distortion (1 kHz) | 0.01 %                      |
| Signal to Noise ratio             |                             |
| KDC-8007                          | 105 dB (1kHz)               |
| KDC-7007                          | 93 dB (1kHz)                |
| Dynamic range                     |                             |
| KDC-8007                          | 100 dB                      |
| KDC-7007                          | 93 dB                       |
| Channel separation                | 85 dB                       |

**Audio section**

|  |                       |
|--|-----------------------|
| Maximum output power                       | 35 W $\times$         |
| Full bandwidth power (at less than 1% THD) | 20 W $\times$         |
| Tone action                                |                       |
| Bass:                                      | 100 Hz $\pm$ 10 d     |
| Treble:                                    | 10 kHz $\pm$ 10 d     |
| Preout level / Load                        |                       |
| KDC-8007 (During CD/disc play)             | 4000 mV/10 k $\Omega$ |
| KDC-7007                                   | 1800 mV/10 k $\Omega$ |
| Preout impedance                           |                       |
| KDC-8007                                   | 80 $\Omega$           |
| KDC-7007                                   | $\leq$ 600 $\Omega$   |

**General**

|   |  |
|---|--|
| Operating voltage                           | 14.4 V (11 – 16 V allowable)             |
| Current consumption                         | 10.0 A at Rated power                    |
| Installation size (W $\times$ H $\times$ D) | 182 $\times$ 53 $\times$ 165 mm          |
|   | 7-3/16 $\times$ 2-1/16 $\times$ 6-1/2 in |
| Weight                                      | 4.0 Lbs (1.8 kg)                         |